NATIONAL SKEET SHOOTING ASSOCIATION



RELEASE TRIGGER STICKER PLACEMENT INSTRUCTIONS

Place the sticker on at least one of these two locations: the underside of the barrel just in front of the forearm or on the grip cap.

This sticker needs to be visible when the gun is in a gun rack so that your release trigger gun is not picked up by accident by a person who is not familiar with release triggers.

SAFETY FIRST

17-Nov-2008

